

ASSEMBLY INSTRUCTIONS – Steps 1 to 9

PARTS LIST

- 2 x (A) post 2-way 41"H
- 2 x (B) post 1-way 41"H
- 1 x (C) post H 2-way 41"H
- 2 x (1) rail aluminum panel 16"H x 36"W
- 2 x (1a) rail aluminum panel 16"H x 24"W
- 2 x (2) panel 16"H x 36"W
- 2 x (2a) panel 16"H x 24"W
- 2 x (3) rail aluminum panel 4"H x 36"W
- 2 x (3a) rail aluminum panel 4"H x 24"W
- 4 x (4) panel cap
- 6 x (5) work top bracket
- 1 x (5a) central cantilever
- 2 x (6) work top 36" x 24"
- 2 x (7) round bracket
- 1 x (8) counter top 48" x 12"
- 5 x (9) post cap kit

Ready-to-Work
Office Cubicles

- TOOLS needed: 1 philips screwdriver or 1 electric drill
- QUESTIONS: call 1-888-880-CUBE or for more info visit www.cubeinabox.com

The counter top is supported by 2 simple brackets in the middle and 2 special round bracket (7)

Tip for (6) and (8)
Use the 3/4" black wood screws with an electric drill from underneath the worktops and counter top

