

ASSEMBLY INSTRUCTIONS – 10 STEPS

PARTS LIST

- 1 x (A) post 1-way 57"H
- 1 x (B) post 2-way 57"H
- 1 x (C) post 2-way 37"H
- 1 x (D) post 1-way 37"H
- 1 x (1) panel 8"H x 41"W
- 1 x (1a) panel 16"H x 53"W
- 1 x (1b) panel 16"H x 27"W
- 1 x (2) raceway panel 41"W
- 1 x (3) rail panel 41"W
- 1 x (4) panel 16"H x 41"H
- 3 x (5) panel cap
- 1 x (6) filler piece
- 4 x (7) work top bracket
- 1 x (8) shelf 41"W
- 1 x (9) work top 53" x 41"
- 4 x (10) post cap kit

Ready-to-Work
Office Cubicles

- TOOLS needed: 1 philips screwdriver or 1 electric drill
- QUESTIONS: call 888-880-CUBE or visit our web site www.cubeinabox.com

Tip for 8
At first, slide down the 2 side parts (chromed wire) on posts, then adjust the shelf on top of the 4 black plastic supports and screw from underneath

Tip for 7
Note the mark on each post to ease height adjustment. You can use a screw driver to squeeze the chromed screw

Tip for 3
The rail panel has to be installed facing up to allow trays to hang on it

Tip for 2
First, slide down the frame of the raceway in between posts A and A, then place the two "cavaliers" (small plastic molded parts) used to hold the doors on each side

Tip for 1 1a 1b
Slide panel (1) in between posts A-B, then panel (1a) in between B-C, and (1b) in between C-D

Tip for 10
Use the 1/2" metal screws to cap the A and B posts

Tip for 9 Use the 3/4" black wood screw with an electric drill from underneath the worktop

