




V5.Series Detailed Assembly Instructions



Tools needed: 1 screwdriver (or drill), Philips head Time of assembly: 20-30 minutes with 2 people

For help call our Toll Free Customer Service at: 1-888-880 CUBE (2823)





| - 2 - | |
|---|---|
| Image: second | Slide panel 6T (41"W) on top of rail-panel 5. Insert the filler designed to hide the empty space on post C. |
| 6 | Assemble and slide/adjust the 2 wire-guides into posts where you will need to fish some cables, preferably under the work-top level. |
| | Slide each support bracket along all the posts and adjust them at the mark level (dot) or at a height of 28-1/4 inches maximum. You simply need to tighten the big chrome-screw to make them hold. |
| 8 | Repeat for all 4 brackets in the inside of the posts. |
| 9 | Display and level the work top then screw it (you may use an electric drill). Use the black wood screws. |

| | - 3 - | |
|----|---------------------------------------|--|
| 10 | | Place the raceway cover on top of the plastic cavaliers on each side of the frame. |
| 11 | | To close the raceway cover, push down on each side of the cover until it clips in. Repeat operation for the second cover (no holes) at the back of the cubicle. |
| 12 | I I I I I I I I I I I I I I I I I I I | Slide each shelf-support into the high posts and adjust the height by tightening the big chrome-screws. |
| 13 | L L | Display the shelf on top of the shelf-supports. Push vertically on each of the 4 black plastic brackets until it fits in. |
| 14 | | Push the shelf all the way toward the panel. Level it with the leveler. Insert the book holders into the holes as shown. |
| 15 | | Place the plastic grommet cap on the work-top hole. Place the metal-caps on top of each post. |

